


Assembly instructions for floating wooden floors

1. Vibrafoam®/Vibradyn® is delivered as pads or strips with Vibisol's mounting glue.
2. Glue the pads/strips on the joists with c/c dimension 600 mm unless otherwise stated.
3. Densification takes place when connected to a wall with a distance of c/c 300 mm, as well as densification at thresholds. At the outer corners, if pads are mounted, 2 pads are laid on each side corner, which prevents a failing floor.
4. With increased load, such as the installation of fixed furnishings such as kitchen counters and fridge and freezer, the floor is reinforced with extra joists. Pads/strips are mounted with c/c 300 mm on the joists.
5. The floor chipboards are laid floating on pads/strips. Do not use nails or screws when mounting the chipboards.
6. Lay 1-3 layers of plaster boards according to the supplier or prescribed instructions. Glue and screw the sheets together, without screwing through the chipboard.
7. The floating floor must be completely free of all walls with an air gap of at least 5 mm to minimize the risk of flank transmission (sound bridge between floor and wall).
8. Parquet or laminate should be installed with an impact sound mat type lump cardboard. For a significantly reduced drum sound, i.e., the sound the floor covering emits in the own room, we recommend our mats insulParq 2+, insulSound Ultra+ and Damtec Standard PUR.
9. The floor plinth should not be directly connected to the floor covering. This is most easily done by mounting an EPDM strip with self-adhesive tape on the underside of the floor plinth.
10. With this assembly, the impact sound has only one way to go, and that is through the pads/strips.



Checklist:

- The c/c dimensions of the pads along the wall and in openings are mounted maximum of 300 mm. The c/c dimensions of the joists are mounted maximum of 600 mm or according to special instructions.
- The strips are mounted along walls and in openings and on the floor with a maximum c/c dimension of 600 mm.
- Only glue is used to attach the pads/strips to the joists.
- No nails or screws may be used between for mounting Vibrafoam®/Vibradyn® pads and strips.
- Parquet or laminate is mounted on lump cardboard or mats with drum sound attenuation according to installation instructions
- Air gap along all walls 5 mm.
- Floor plinth is mounted with an EPDM strip.



Edition April 2021

VIBISOL